

**To Connect to the Internet We Use a Login Called PPPOE.**

**If you need to redo a PPPoE client connection(in case of computer Failure), follow these steps:**

**Windows XP:**

1. Click Start, click Control Panel, and then double-click Network and Internet Connections.
2. Click Network Connections, and then click Create a new connection
3. After the Network Connection Wizard starts, click Next.
4. Click Connect to the Internet, and then click Next.
5. Click Set up my connection manually, and then click Next.
6. Click either Connect using a broadband connection that requires a user name and password or Connect using a broadband connection that is always on.
7. Type the Internet service provider (ISP) name that your ISP provided, and then click Next.
8. Type the user name that the ISP provided.
9. Type the password that the ISP provided.
10. Type the password one more time to confirm it, and then click Next.
11. Click Add a shortcut to this connection to my desktop.
12. Click Finish to complete the wizard.

**For Windows Vista and Windows 7:**

1. Click "Start menu"
2. Click "Control Panel"
3. Click "Network & Sharing Center"
4. Click "Set up a connection or network"
5. Select "Connect to the Internet" -> Click "Next"
6. Click "Broadband (PPPoE)"
7. Type in your user name as provided by your service provider
8. Type in your password as provided by your service provider
9. Click "Connect"
10. If successful you will see a message that the connection is ready and you can click "Close"

**Linksys Router:**

1. Go to your desktop and double click on Internet Explorer (Located on the Start Menu in Windows XP)
2. When "Internet Explorer" opens type 192.168.1.1 into the "Address" bar and click on Go
3. The "Enter Network Password" window will appear.
4. Skip user name and type admin (admin is the default password) as the password, and click OK
5. Scroll down on this page and look for (on older firmware) PPPoE or select the option for PPPoE under "WAN Connection type"
6. Username:
7. Password:
8. Select the option for Connect on Demand: Max Idle Time 9999 Min.
9. Click on the Apply button.
10. Then click on the Save Settings button
11. Exit Internet Explorer